



PART LIST

No.	PART NAME	Qty
2	Upper hinge cover	1
3	Screw	2
4	Upper hinge	1
5	GLASS DOOR	1
6	DOOR SEAL	1
7	Display board	1
8	Fan cover	1
9	fan	1
10	wine basket	1
11	wire shelve	4
12	down hinge	1
13	Screw	2
14	switch cover	1
15	fan switch	1
16	adjust feet	1
17	power cord	1
18	power cord fixer	1
19	screw	1
20	Evaparator Pan	1
21	screw	2
22	Evaparator Pan button	2
23	dryer	1
24	Compressor base plate	1
25	screw	4
26	compressor wire	1
27	control board	1
28	control board box	1
29	control board box cover	1
30	compressor	1
31	Screw	1
32	overload protector	1
33	PTC Starter	1
34	Compressor Relay Cover	1
35	Compressor Relay clip	1
36	control board box fixer	1